



## **KEYED NOTES:**

1 REPAIR EXISTING OPERABLE WINDOWS WHERE CURRENTLY INOPERABLE

**GENERAL NOTES:** 

1. TUCKPOINT EXISTING MASONRY FACADE. USE A SAND BASED MORTAR, COLORED TO MATCH EXISTING JOINTS

2. REPAIR ANY CRACKS IN THE MASONRY,

REMOVE EXISTING BRICK IN AREA OF CRACK, SALVAGE AND REBUILD AS

3. INSPECT ALL EXISTING LINTELS AT

- 2 EXISTING WINDOW TO REMAIN, REPAIR FRAME AND SASH AFTER STORM WINDOW IS REMOVED
- REPAINT EXISTING CONCRETE BLOCK SURFACES
- 4 -



Sheet Number:

A5.11(R)

© 2024 studiozONE, Ilc