







## **KEYED NOTES:**

- 1 NEW STOREFRONT SYSTEM AT EXISTING MASONRY OPENING, CLEAR ANODIZED ALUMINUM STOREFRONT W/ CLEAR, TEMPERED GLASS
- 2 REPAIR EXISTING WINDOW WINDOW SASH WHERE AIR CONDITIONER WAS REMOVED
- 3 INSTALL GLASS BLOCK IN EXISTING MASONRY OPENING
- INSTALL NEW GLASS IN EXISTING
  ALUMINUM WINDOW FRAME AFTER
  REMOVE OF WINDOW AIR
  CONDITIONER
- 5 REPAIR MASONRY AFTER REMOVAL OF EXISTING CANOPY AT ENTRANCE
- 6 REPAIR EXISTING OPERABLE WINDOWS WHERE CURRENTLY INOPERABLE
- REMOVE EXISTING PAINT AT CORNICE WHERE LOOSE, STRIP DOWN TO BARE WOOD OR WHERE PAINT IS FULLY ADHERED, PRIME AND REPAINT
- REPAIR EXISTING LIMESTONE HEAD AND SILL WHERE DAMAGED, STONEPATCH MATCHING COLOR FOR DAMAGED AREAS LESS THAN 3" IN WIDTH, FOR LARGER THAN 4", CUT IN NEW DUTCHMAN STONE PIECE, ALL REPAIRS TO MATCH EXISTING STONE COLOR
- 9 EXISTING WINDOW TO REMAIN, REPAIR FRAME AND SASH AFTER STORM WINDOW IS REMOVED
- 10 -
- 11 -
- 12 -

## **GENERAL NOTES:**

- 1. TUCKPOINT EXISTING MASONRY FACADE. USE A SAND BASED MORTAR, COLORED TO MATCH EXISTING JOINTS
- 2. REPAIR ANY CRACKS IN THE MASONRY, REMOVE EXISTING BRICK IN AREA OF CRACK, SALVAGE AND REBUILD AS REQUIRED.
- 3. INSPECT ALL EXISTING LINTELS AT MASONRY OPENINGS. ANY DAMAGED LINTELS ARE TO BE REMOVED AND REPLACED W/ A NEW LINTEL.



A5.10 (R)

© 2024 studiozONE, Ilc

PROPOSED ELEVATIONS